

Summary of status of DCATT components

OPTIC	Description	Physical	Optical	Status
Beamsplitter	ZYGO corporation	BK-7, 1.5 inches diameter, .25 in thick Wedge 15 arcminutes	Transmitted wavefront distortion /20 scracth dig 60/40	Expected delivery August 20
OAP1	Lambda/Ten (McPherson) First off-axis parabola	8 inches diameter, 9 inch off-axis distance	Measured Figure:less than /20 PV @633 rms Measured surface roughness less than 10 Angstroms	Delivered, Coated, Reflectance > 90%, microrouphness measured Mounted
FLAT1	Lambda/Ten (McPherson)	6 inch diameter mirror	Measured Figure:less than /18 PV @633 rms Measured surface roughness less than 10 Anostroms	Delivered,Coated, Reflectance > 90%, microrouphness measured Mounted
DM	Xinetics 349 Actuator deformable mirror, 7 mm spacing, 4 micron stroke	clear aperure 147 mm	Figure /14,Scracth dig 60/40, Surface finish <15	Delivery expected August 24 Software already here.
OAP2	Lambda/Ten (McPherson	8 inches diameter, 9 inch off-axis distance, ~ 2 inches thick	Measured Figure:less than /18 PV @633 rms Measured surface roughness less than 10 Angstroms	Delivered, Coated, Reflectance > 90%, microrouphness measured Mounted
FSM/FLAT2	Lambda/Ten (McPherson	6 inch diameter mirror	Measured Figure:less than /25 PV @633 rms Measured surface roughness less than 10 Angstroms	Delivered, Coated, Reflectance > 90%, microrouphness measured Mounted
DFS (Grism)	Spectronics Instrument (formally-Richarson grating Lab)	25 x 25 x 4.5 mm	Blazed for 600 nm 35 groves per mm prism apex angle 2.46 deg	Delivered to GSFC needs mounting

Optics Branch

Optics Branch

MASA/GSFC



DCATT Project Review

Aft Optics components and Alignment

Ray Boucarut





Beamsplitter

Diameter 1.5 inches (38 mm)

Thickness .25 (6.35 mm)

Material BK-7

Vendor ygo Corporation

Surface figure /20 in transmittance

and reflectance over

diameter of piece

Active Area 24 mm

Coating Strategy

- •Multiple substrates purchased
- •Initially metal coatings e.g.

Aluminum - In house

- Dielectric coatings
- •Antireflection coating

Current Status

Waiting for delivery of substrates





DCATT PROJECT Review AO Bench Components and Alignment plan Off Axis Parabolas

Specifications

Vendor Lambda Ten Corporation

Diameter 8 inches (200 mm)
Off Axis 9 inches (227 mm)

distance

Material Zerodur
Active Area 164_{mm}

Focal Length 80 in. (2032 mm)

Surface figure /18 over diameter of piece


Surface microroughness Measured : < 10 Angstroms





Current Status

- •Alignment cubes
- •Phase Interferometry for figure
- •Mounts Available
- •Mirrors coated at GSFC



Optics Branch

Optics Branch

NASA/GS/80



Large flat mirror

Specifications

Vendor Lambda Ten Corporation

Diameter 6 inches (152 mm)

Material Zerodur

Surface /25 PV in over diameter of piece

figure 0.008 waves rms

Surface micro- Measured < 10 Angstroms


roughness

Status

Spare mirrors to be used in alignment


Mounts developed for mirror

Mirrors coated at GSFC









Optics Branch






Deformable Mirror

Specifications

349 Actuators, 7 mm spacing

- •Ultra low expansion face sheet
- •PMN multilayer actuators, low hysteresis
- •147 clear aperture and reflective diameter
- •Mechanical stroke 4 µm
- •Surface finish < 15 Angstroms
- •Frequency response full stroke at 1 khz
- •Present software allows uploads of table file of values to mirror.
- •Software is also capable of monitoring of Zener diode protection



Status

- •Manufacturer Xinetics expect to ship next week
- •Already fully tested and is being integrated





Incident


Light

DCATT PROJECT Review

AO Bench Components and Alignment plan


DFS Grism

Vendor	Spectronics (Richardson)	
Size	25 x 25 mm	
Active Area	18.5 mm	
Material	BK-7	
Center thickness	4.5 mm	
Prism Angle	2.464 degrees	
Blaze angle	2.2 degree	
Groove density	35 grooves/mm	
Grating Order	1	
Wavelength range	475 – 900 nm	



Status

- •delivered last week
- •mount being developed
- •characterization plan being written







Other components available

- Wavescope Shack- Hartmann InterferometerRelay optics
- •CCD Camera
- Spare Optics
- •Tungsten Source
- Stabilized laser
- Microscope Objective





DM testing sequence

Deformable Mirror Flatness

Vverifies performance of DM Ddata necessary input for error budget Wwill achieve and measure flatness at various voltages

Influence Profile


- -Determine influence of neighboring actuator as a function of position
- -Determine how closely DM simulation model is followed

Gain Curve Determination

- -This information is needed to correctly model the DM
- -A series of calibrated gain curves will be developed for a significant sample of the actuators

Hysteresis

- -Necessary to correctly model the DM
- -The goal is obtain repeatable gain curves



Stability

-Determine the long and short stability and repeatability of the DM actuated system Temperature Dependence

- This tests the stability of gain curves over a temperature range


Option Branch





Alignment method

- •Defining location of DCATT master reference
- •Elements will be aligned in sequence
- •Physically placement of elements in approximate location
- •Using alignments cubes and flats for more precise adjustments
- •Using Interferometer along with insertion of retro flat for final alignment





DFS calibration

•Plan is currently under development

•Will probably use AO layout with white light, CCD camera and monochromator

